

STEP 1: ASSEMBLE YOUR BRACKET

FOR A 4 RIB BRACKET:

SPOT AND DRILL THE REQUIRED HOLES THROUGH THE RIBS.



IF YOU ARE USING A 2 OR 4 RIB BRACKET:

ASSEMBLE THE PARTS AND ATTACH THEM TO THE MANHOLE LID. BE SURE TO TIGHTEN THE BRACKET TO CLENCH THE LID.



IF YOU ARE USING A BULKHEAD

SPOT AND DRILL THE REQUIRED HOLD THROUGH THE DOME OF THE TANK.

ASSEMBLE THE COMPONENTS AND CLENCH THE DOME.

BE SURE TO TIGHTEN THE BULKHEAD.



STEP 2:

PUT YOUR MIXING SHAFT THROUGH THE BRACKET



STEP 3:

PLACE THE MIXING SHAFT INTO THE DRIVE'S OUTPUT AND FASTEN THE TWO SET SCREWS



STEP 4:

FASTEN DRIVE INTO THE BRACKET



STEP 5:

TO REMOVE, UNSECURE THE MIXER AND PULL OUT OF CONTAINER